PARTS LIST

DDL-900C
PARTS LIST

下記 URL より、便利な検索機能のついた Web Parts List をご利用頂けます。
ご利用には会員登録が必要です。(無料)
https://www.juki.co.jp/partslist/

You can use a Web Parts List with a convenient search function from the URL below. To use this website, free membership registration is required.
https://www.juki.co.jp/partslist/

No.1767-10

HOW TO MAKE USE OF THIS PARTS LIST

1.Explanation of codes

1)"*"mark.....means this part is changed from the previous parts book.

As to the details of the change,refer to "List for information of change".

2)"#01".....refer to "Note" explanation at bottom of page.

2.Codes on the "Qty" column

・Each numeral indicates the number of parts required.

・"0.1" and "2.5" indicate the length (in meters) of the respective parts.

3.Parentheses mean that the corresponding part is a subpart that constructs an assembly part.

4.Dotted lines on the Figures indicate assembly parts.

5.As to the parts with marks of " ☆ "(consumable parts) and " ◎ "(optional parts)on the respective parts, it is recommended to prepare spares.

パーツリストご利用に際して

１．" 注記 " 欄の記号説明

１）" ＊ " 印 ..... 前回のパーツブックに比較して今回変更された部品を意味します。

変更内容は " 変更情報リスト " を参照してください。

２）"#01"..... ページ下の " 注記 " の説明を参照してください。

２．数量欄の数字は、個数を表し、0.1、2.5 等の数値は、長さ（単位メートル）を表します。

３．数量欄の（　）は、組部品を構成している子部品であることを意味します。

４．イラストページのーーーーー枠は、組構成であることを意味します。


５．リストページの " ☆ "（消耗部品）、" ◎ "（オプション部品）の印がついた部品は、予備を準備しておくことをお奨めします。

CONTENTS
目　次

1. MACHINE FRAME & MISCELLANEOUS COVER COMPONENTS 1
頭部・外装関係
2. UPPER SHAFT AND PICK LINE COMPONENTS 3
上軸・天秤関係
3. NEEDLE BAR & THREAD TENSION COMPONENTS 5
針棒・糸調子関係
4. HAND LIFTER COMPONENTS 7
押え上げ関係
5. UPRIGHT SHAFT & HOOK DRIVING SHAFT COMPONENTS 9
立軸・下軸関係
6. FEED MECHANISM COMPONENTS 11
送り関係
7. FEED ADJUST MECHANISM COMPONENTS 13
送り調節関係
8. THREAD TRIMMER COMPONENTS 15
糸切り関係
9. AUTOMATIC REVERSE FEED & NB COMPONENTS 17
自動逆送り・ＮＢ 関係
10. OIL LUBRICATION COMPONENTS 19
給油関係
11. OIL SHIELD COMPONENTS 21
オイルシールド関係
12. THREAD STAND COMPONENTS 23
糸立装置関係
13. ACCESSORIE PART COMPONENTS 25
付属品関係
14. FOR HEAVY-WEIGHT MATERIALS 27
厚物専用
15. LIST FOR INFORMATION OF CHANGE 29
変更情報リスト
NUMERICAL INDEX OF PARTS 30
索引

1. MACHINE FRAME & MISCELLANEOUS COVER COMPONENTS


頭部・外装関係



REF.NO	NOTE	PART NO	D E S C R I P T I O N	品　名	Qty
1		402-63284	FACE PLATE	面板	1
2		402-63285	FACE PLATE GASKET	面板パッキン	1
3		402-63286	OIL WINDOW	油窓	1
4		402-63287	THRUST COLLAR ASM	油窓Oリング	1
5		402-63288	RUBBER PLUG	止栓	5
6		402-63289	RUBBER PLUG	止栓	1
7		402-63290	SCREW	止ねじ	8
8		402-63291	SIDE PLATE	窓板	1
9		402-63292	SIDE PLATE GASKET	窓板パッキン	1
10		402-63293	OVER LINE BOARD	第一糸案内	1
11		402-63294	RUBBER SLEEVE	頭部支え棒ゴム	1
12		402-63295	RUBBER PLUG	止栓	1
13		402-62397	SCREW	止めねじ	2
14		402-63297	SCREW	止ねじ	2
15		402-63298	WIRE CLAMP	コード押え	2
16		402-63299	SCREW	止ねじ	2
17		402-63302	BED SCREW STUD(ONE)	ベッド支柱１	4
18		402-63303	BED SCREW STUD(TWO)	ベッド支柱２	1
19		402-63326	SAFETY-INDICATING PLATE	安全注意シール	1
20		402-63305	SCREW	止ねじ	3
21		402-63306	THREAD CUTTER	糸巻糸切り	1
22		402-63307	SCREW	止ねじ	2
23		402-63308	SCREW	止ねじ	1
24		402-63309	THREAD TAKE-UP LEVER COVER	天秤カバー	1
25		402-63310	RIGHT ARM THREAD GUIDE	天秤糸案内	1
26		402-63311	SCREW	止ねじ	2
27		402-63312	LARGE ARM THREAD GUIDE	アーム糸案内	1
28		402-63313	NEEDLE PLATE	針板	1
29		402-63314	SCREW	止ねじ	2
30		402-63315	RULER PLATE	定規板	1
31		402-63316	SCREW	止ねじ	1
32		402-63317	SLIDE PLATE ASM	滑り板組	1
33		402-63318	SLIDE PLATE	滑り板	(1)
34		402-63319	SPRING OF SLIDE PLATE	滑り板ばね	(1)
35		402-63320	SCREW	止ねじ	(2)
36		402-63321	SCREW	止ねじ	6
37		402-63322	RUBBER PLUG	止栓	2
38		229-02506	PLATE	面板化粧板	1
39		402-63323	BOBBIN THREAD TENSION ASM	糸巻糸案内	4
40		402-63324	BOBBIN WINDER ASM	糸巻装置組	1
41		402-64679	BTW_LEVER	糸巻レバー	(1)
42		403-00798	WHEEL_RUBBER	糸巻き摩擦車	(1)
43		402-59438	CONTROL_BOX_1P_220_240V	電装ボックス組２２０－２４０Ｖ	1
44		402-59439	OPERATING SCREEN	パネル９０００Ｃ組	1
45		402-63330	SCREW	止ねじ	2
46		402-63333	A KNOB	つまみ	1
47		402-63334	LEFT ARM THREAD GUIDE	糸案内ガイド	1
48		402-63335	NUT	ナット	1
49		402-63336	OIL WINDOW	油量台	1
50		402-63337	RUBBER PING	Oリング	1
51		402-63338	OIL WINDOW	油量窓	1
52		402-63339	HOLE COVER	穴カバー	1
53		402-63340	GASKET	パッキン	1
54		402-63341	RUBBER PLUG	止栓	1
55		402-63342	SCREW	止ねじ	1
56		402-63343	CORD HOLDER(S)	コード止Ｓ	2
57		402-63344	CORD HOLDER(L)	コード止Ｌ	2
58		402-64671	SCREW	止めねじ	1
59		402-64672	SCREW	止めねじ	3
60		402-64673	CONTROL_BOX_COVER	電装カバー	1
61		402-64674	SCREW	止めねじ	2
62		402-63574	SCREW 9/64-40 L=6	止ねじ	1
63		402-63325	GASKET SEALE	糸巻装置パッキン	1
64		402-62399	BED_OIL_SHIELD	ベッド油防板	1

2. UPPER SHAFT AND PICK LINE COMPONENTS


上軸・天秤関係



REF.NO	NOTE	PART NO	D E S C R I P T I O N	品　名	Qty
1		402-63346	MAIN SHAFT	上軸	1
2		402-63347	COUNTER WEIGHT	釣合錘	1
3		402-63348	SCREW	止ねじ	4
4		402-63349	SCREW	止ねじ	1
5		402-63350	SCREW	止ねじ	1
6		402-63351	O RING	Oリング	1
7		402-63352	FRONT BUSHING OF MAIN SHAFT	上軸前メタル	1
8		402-63353	MID BUSHING OF MAIN SHAFT	上軸中メタル	1
9		402-63354	SCREW	止ねじ	1
10		402-63355	OIL SEAL	オイルシール	1
11		402-63356	REAR BUSHING OF MAIN SHAFT	上軸後メタル	1
12		402-63357	MOTOR	主モータ	1
13		402-63358	THE GASKET	ガスケット	(1)
14		402-63359	MOTOR STATOR	ステータ	(1)
15		402-63361	SCREW	止ねじ	(3)
16		402-63301	WASHER	座金	(4)
17		402-63362	SCREW	止ねじ	(4)
18		402-63363	MOTOR ROTOR	ローター	(1)
19		402-64676	ENCODER ASM.	エンコーダー(組)	(1)
20		402-63365	SCREW	止ねじ	(2)
21		402-64677	RUBBER PLUG	止栓	(1)
22		402-63371	THREED TAKE-UP CRANK SHAFT	天秤支え軸	1
23		402-63372	THREED TAKE-UP ASM.	天秤組	1
24		402-63373	SCREW	止ねじ	(1)
25		402-63374	BEARING	ベアリング	(2)
26		402-63375	NEEDLE BAR CONNECTING ROD	針棒クランクロッド	(1)
27		402-63376	THREED TAKE-UP SHAFT	針棒クランク	(1)
28		402-63377	THREED TAKE-UP	天秤	(1)
29		402-63378	THREED TAKE-UP CONNECTING ROD	天秤支え	(1)
30		402-63383	GASKET SEALE	油芯	(1)
31		402-63330	SCREW	止ねじ	2
32		402-63380	SCREW	止ねじ	1
33		402-63381	RETAINING RING	スラストカラー	2
34		402-63382	RETAINING RING	Cリング	1
35		402-63379	WHEEL	糸巻車	1
36		402-63384	THE ADJUST PIN	面部油量調節ピン	1
37		402-63385	SIDE PLATE GASKET	クランク油量調節カラー	1
38		402-63386	THRUST COLLAR ASM	Oリング	1
39		402-63387	OIL FELT	フェルト	1
40		402-99184	HEAD WHEEL	はずみ車	1
41		402-63366	SCREW	止ねじ	2
42		402-64696	SCREW	止ねじ	2


3. NEEDLE BAR & THREAD TENSION COMPONENTS

針棒・糸調子関係



REF.NO	NOTE	PART NO	D E S C R I P T I O N	品　名	Qty
1		402-63388	RUBBER PLUG	止栓	1
2		402-63389	UPPER BUSHING OF NEEDLE BAR	針棒上メタル	1
3		402-63390	NEEDLE BAR	針棒	1
4		402-63391	NEEDLE BAR HOLDER	針棒抱き	1
5		402-63392	SCREW 9/64-40 L=6	止ねじ	1
6		402-63393	LOWER BUSHING OF NEEDLE BAR	針棒下メタル	1
7		402-63394	NEEDLE BAR THREAD GUIDE	針棒糸掛け	1
8		402-63395	NEEDLE(DBX1#14)	針	1
9		402-63396	SCREW 1/8-44 L=4.5	止ねじ	1
10		402-63397	NEEDLE BAR THREAD GUIDE	針棒糸案内	1
11		402-63398	SLIDE BLOCK	コロ案内台組	1
12		402-64681	FIRST_THREAD_TENSION_ASM.	第一糸調子(組)	1
13		402-63399	THREAD TENSION SPRING	第一糸調子台	(1)
14		402-63401	BOBBIN WINDER TENSION DISC	第一糸調子皿	(2)
15		402-63402	THREAD TENSION SPRING	第一糸調子ばね	(1)
16		402-63403	THREAD_TENSION_NUT	糸調子ナット	(1)
17		402-64680	THREAD_TENSION_ASM.	糸調子(組)	1
18		402-63405	TENSION POST SOCKET	第二糸調子棒台	(1)
19		402-63406	SCREW 15/64-28 L=7	止ねじ	(1)
20		402-63407	TAKE-UP SPRING	糸取りばね	(1)
21		402-63408	THREAD_TENSION_POST	糸調子棒	(1)
22		402-63409	TENSION DISC	第二糸調子皿	(2)
23		402-63410	TENSION DISC HOLDER	第二糸調子皿受	(1)
24		402-63411	TENSION SPRING	第二糸調子ばね	(1)
25		402-63412	TENSION DISC STOPPER	第二糸調子皿ストッパー	(1)
26		402-63413	TENSION NUT	第二糸調子ナット	(1)
27		402-63404	SET SCREW 9/64-40 L=4	止ねじ	(1)
28		402-63415	TENSION RELEASE PIN SPRING	皿緩め戻しばね	1
29		402-63416	TENSION RELEASE SUPPORTING PIN	皿緩め棒	1
30		402-63330	SCREW 11/64-40 L=6	止ねじ	1
31		402-63417	SLIDE BLOCK 11/64-40 L=8	角駒ガイド止ねじ	2
32		402-63418	SCREW	止ねじ	2
33		402-63419	MOUNTING PLATE	糸緩めＳＯＬ板	1
34		402-63420	LOOSE WIRE ELECTROMAGNET	糸緩めソレノイド	1
35		402-63290	SCREW	止ねじ	2
36		402-63421	ELECTROMAGNET COVER	糸緩めＳＯＬカバー	1
37		402-63422	SCREW	止ねじ	2
38		402-63423	GASKET SEALE	油防板	1
39		402-63400	SNAP RING	Ｅリング	1
40		402-63414	THREAD RELEASE PIN	皿緩めピン	1


4. HAND LIFTER COMPONENTS
押え上げ関係



REF.NO	NOTE	PART NO	D E S C R I P T I O N	品　名	Qty
1		402-63424	PRESSER SPRING REGULATOR	押え圧調節ねじ	1
2		402-63425	NUT 1/2-28	押え圧調節ねじナット	1
3		402-63426	PRESSER GUIDE BAR	押えばねガイド	1
4		402-63427	PRESSER SPRING	押えばね	1
5		402-63428	PRESSER GUIDE BAR	押え棒	1
6		402-63429	NEDDLE BAR GUIDE BRACKET	押え棒抱き	1
7		402-63430	SCREW 1/4-40 L=8	止ねじ	1
8		402-63431	PIN	ピン	1
9		402-63432	PRESSER BAR BUSHING LOWER	押え棒メタル	1
10		402-63433	PRESSER FOOT ASM.	押え組	1
11		402-63434	SCREW 9/64-40 L=10.5	止ねじ	1
12		402-63435	HAND LOFTER	手動レバー	1
13		402-63434	SCREW 9/64-40 L=10.5	止ねじ	1
14		402-63436	HAND LOFTER CAM ASM.	手動レバーカム組	1
15		402-63437	RUBBER RING	Ｏリング	1
16		402-63468	KNEE LIFTING COSS ROD ASM.	膝上げ横棒組	1
17		402-63439	HAND LIFTER LINK ASM.	手動リンク組	(1)
18		402-63438	LIFTING LEVER	押えレバー	(1)
19		402-63441	SNAP RING	Ｅリング	(5)
20		402-63448	FLAT MAT	押え上げ戻しばね	(1)
21		402-63447	LIFTING LEVER CONNECTING ROD	押え上げ棒	(1)
22		402-63451	HINGE SCREW 3/16-32	段ねじ	1
23		402-63445	AXLES	押え上げクランク棒	1
24		402-63440	THREAD PIN	ピン	1
25		402-63443	FOOT UP CRANK TWO	押え上げクランク２	1
26		402-63449	LIFTING LEVER LINK	押え上げリンク	1
27		402-63450	HINGE SCREW 15/64-28	段ねじ	1
28		402-63452	CONNECTING ROD	膝上げ押し棒	1
29		402-63442	RETAINING_RING	Ｃリング	2
30		402-63446	SCREW	止ねじ	1
31		402-63454	FOOTUP CRANK THREE	押え上げクランク３	1
32		402-63455	TORSION SPRING	戻しばね	1
33		402-63456	THE GASKET	ガスケット	1
34		402-63457	PRESSER FOOT PAD	押え足上げ板	1
35		402-63458	FOOT BLOCK	押え足上げ	1
36		402-63459	SPRING WASHER	波座金	2
37		402-63460	SCREW	止ねじ	2
38		402-63461	HINGE_SCREW	段ねじ	1
39		402-63462	ROLLER	コロ	1
40		402-63366	SCREW	止ねじ	1
41		402-63464	PUSH-UP CRANK	押し上げクランク	1
42		402-63465	NUT	ナット	1
43		402-63467	PRESSER BAR OIL SEAL	押え棒油防ゴム	1
44		402-63444	SCREW	止ねじ	4
45	*	402-90629	SHAFT SLEEVE	押え足上げメタル	1
46		402-63470	GASKET SEALE	オイルシール	1


5. UPRIGHT SHAFT & HOOK DRIVING SHAFT COMPONENTS

立軸・下軸関係




REF.NO	NOTE	PART NO	D E S C R I P T I O N	品　名	Qty
1	#01	402-63471	HOOK_ASM.(M)	釜(組)__M仕様	1
2		402-63472	BOBBIN CASE ASM.	ボビンケース	1
3		402-63473	BOBBIN	ボビン	1
4		402-63474	SCREW	止ねじ	2
5		402-63475	POSTIONING FINGER	中釜押え	1
6		402-63476	SCREW 11/64-40 L=9.5	止ねじ	1
7		402-63477	HOOK DRIVING SHAFT	釜軸	1
8		402-63478	OIL SEAL SCREW ASM.	釜軸油芯ねじ	1
9		402-63479	OIL WICK	釜軸油芯	1
10		402-63480	FRONT BUSHING	釜軸前メタル	1
11		402-63474	SCREW	止ねじ	1
12		402-63482	REAR BUSHING	釜軸後メタル	1
13		402-64697	SCREW	止めねじ	1
14		402-63495	THRUST_COLLAR	スラストカラー	1
15		402-63484	SCREW 1/4-40 L=8	止ねじ	2
16		402-63485	BEVEL GEAR SMALL	傘歯車下（小）	1
17		402-63486	SCREW 1/4-40 L=8	止ねじ	8
18		402-63487	BEVEL GEAR LARGE	傘歯車下（大）	1
19		402-63488	LOWER BUSHING	立軸下メタル	1
20		402-63489	UPPER BUSHING	立軸上メタル	1
21		402-63490	SCREW 11/64-28 L=9	止ねじ	1
22		402-63491	UPRING SHAFT	立軸	1
23		402-63492	BEVEL GEAR SMALL	傘歯車上（小）	1
24		402-63493	BEVEL GEAR LARGE	傘歯車上（大）	1
25		402-63494	OIL SEAL 18	オイルシール	1
26		402-63495	THRUST_COLLAR	スラストカラー	1
27		402-63496	SCREW 1/4-40 L=8	止ねじ	2
28		402-63470	OIL SEAL 12	オイルシール	2
29	#02	402-64689	HOOK_ASM.(M)	釜(組)__M仕様	1
		NOTE(注記)	#01....FOR CHINA #02....FOR GENERAL EXPORT	中国向け 一般輸出用	

6. FEED MECHANISM COMPONENTS
送り関係




REF.NO	NOTE	PART NO	D E S C R I P T I O N	品　名	Qty
1		402-64682	CONNECTING ROD ASM. M-TYPE	水平上下偏心カム組M	1
2		402-63497	FEED DRIVE ECCENTRIC CAM ASM.	送り偏心カム組	(1)
3		402-63499	SCREW 1/4-40 L=11	止ねじ	(2)
4		402-63500	THRUST COLLAR	送り偏心カム蓋	(1)
5		402-63501	SCREW 9/64-40 L=5	止ねじ	(2)
6		402-63498	FEED DRIVE ECCENTRIC CAM	送り偏心カム	(1)
7		402-63503	WALKING FOOT PIN	ロッド軸	(1)
8		402-63504	SCREW 9/64-40 L=6	止ねじ	(1)
9		402-63505	LONG WALKING FOOT LINK	連結リンク長	(2)
10		402-63506	SHORT WALKING FOOT LINK	連結リンク短	(2)
11		402-63536	SNAP RING	Cリング	(1)
12		402-63508	WALKING FOOT ADJUST LINK	送り調節体	(1)
13		402-63535	CONNECTING ROD	上下送りロッド	(1)
14		402-63534	HINGE_SCREW	段ねじ	(1)
15		402-63502	ROCKER SHAFT CONNECTING ROD	送り偏心カムロッド	(1)
16		402-63513	FEED ROCKER SHAFT CRANK ASM.	水平送り腕	(1)
17		402-63515	SCREW 9/64-28 L=14	止ねじ	(1)
18		402-63528	REAR CRACK ASM.	上下送り腕	(1)
19		402-63529	SCREW 3/16-28 L=12	止ねじ	(1)
20		402-63533	NUT	ナット	(1)
21	*	402-93984	FEED ROCKER SHAFT	水平送り軸	1
22		402-63517	SCREW	止ねじ	1
23		402-63518	SCREW	止ねじ	1
24		402-63519	FEED CRACKET	送り台腕	1
25		402-90628	FEED BAR SHAFT	水平送り台軸	1
26		402-63521	FEED ROCKER SHAFT BUSHING	水平送り軸前メタル	1
27		402-63522	RUBBER PLUG	ゴム栓	1
28		402-63523	RETAINING RING	Cリング	2
29		402-63524	FEED DRIVING SHAFT BUSHING	上下送り軸前メタル	1
30		403-06440	DRIVING_SHAFT_CRANK_ARM	上下送り台腕	1
31		402-63526	SCREW 11/64-40 L=10.5	止ねじ	1
32		402-63527	FEED DRIVING SHAFT	上下送り軸	1
33		402-63507	WALKING FOOT PIN	連結リンク軸	2
34		402-63512	FEED DRIVING SHAFT BUSHING	水平送り軸メタル	1
35		402-63530	FEED ROCKER BASE ASM.	送り台	1
36		402-63531	FEED DOG	送り歯	1
37		402-63532	SCREW 1/8-44 L=6	止ねじ	2
38		402-63510	FULCRUM_SHAFT_LONG	支点軸長	1
39		402-63511	SCREW 15/64-28 L=7	止ねじ	2
40		402-63509	FULCRUM_SHAFT_SHORT	支点軸短	1
41		402-63514	WALKING FOOD PIN	水平送り腕ピン	1
42		402-63537	RUBBER PLUG	ゴム栓	2
43		402-63538	OIL WICK	油芯	1
44		402-63539	THRUST_COLLAR	スラストカラー	2
45		402-63540	SCREW 1/4-40 L=4	止ねじ	4
46		402-63541	OIL SEAL 22	オイルシール	2
47		402-63542	BUSHING MID	上下送り軸中メタル	2
48		402-63543	RUBBER_PLUG	ゴム栓	1
49		402-63544	RUBBER PLUG	ゴム栓	2
50		402-63545	THE GASKET	ガスケット	1
51		402-64678	BUSHING REAR	送り軸後メタル	2
52		402-63504	SCREW 9/64-40 L=6	止ねじ	3
53	*	402-90621	RUBBER PLUG	ゴム栓	1

7. FEED ADJUST MECHANISM COMPONENTS
送り調節関係



REF.NO	NOTE	PART NO	D E S C R I P T I O N	品　名	Qty
1		402-63546	HINGE_SCREW	段ねじ	2
2		402-63547	EXTERNAL CONNECTING ROD	連結リンク	1
3		402-63366	SCREW	止ねじ	2
4		402-63548	MOTOR CRANK	モーター腕	1
5		402-63366	SCREW	止ねじ	2
6		402-63550	ADJUSTER CRANK	調節腕	1
7		402-63551	OIL SEAL	オイルシール	1
8		402-63552	ADJUSTER SHAFT	調節軸	1
9	*	402-90622	REGULATING SLEEVE	調節軸メタル	1
10		402-63554	ADJUSTER	送り調節器	1
11		402-63555	SNAPRING	Eリング	2
12		402-63556	FEED ROD	送り調節ロッド	1
13		402-63557	CONNECTING ROD PIN	送り調節ロッドピン	1
14		402-63446	SCREW	止ねじ	2
15		402-63558	SCREW	止ねじ	1
16		402-63559	MOUNTING PLATE	送りモーター土台	1
17		402-63560	SCREW	止ねじ	4
18		402-63561	REGULATING MOTOR	送りモータ	1
19		402-63562	SCREW	止ねじ	4
20		402-63563	SPRING MAT4	波座金	4
21		402-63564	SPRING MAT5	波座金	4
22		402-63565	MOTOR COVER BOX	モーターカバー	1
23		402-63566	PROTECTION PLATE	保護板	1
24		402-63299	SCREW	止ねじ	4
25		402-63290	SCREW	止ねじ	3


8. THREAD TRIMMER COMPONENTS
糸切り関係




REF.NO	NOTE	PART NO	D E S C R I P T I O N	品　名	Qty
1		402-63567	DRIVE MOTOR	駆動モーター	1
2		402-63568	WASHER	座金	1
3		402-63446	SCREW	止ねじ	1
4		402-63570	FIXED KNIFE	固定メス	1
5		402-63571	FIXED ROUND KNIFE BRACKET	固定メス土台	1
6		402-63572	DISPART THREAD SHUTTLE	さばき板	1
7		402-63573	NUT 11/64-40	ナット	1
8		402-64699	SCREW	止ねじ	1
9		402-63575	MAIN ROUND KNIFE BRACKET	動メス土台	1
10		402-63576	KNIFE HOLDER PRESSER PLATE	糸切り固定板	1
11		402-63577	SCREW M4	止ねじ	2
12		402-63578	SCREW M3 L=8	止ねじ	3
13		402-63579	DRIVING KNIFE	動メス	1
14		402-63580	SCREW 11/64-40	止ねじ	3
15		402-63581	KNIFE SHAFT CRANK ROD	メス軸リンク	1
16		402-63582	SCREW 11/64-40	止ねじ	2
17		402-63583	NUT M4	ナット	2
18		402-63584	TRIMMING CRANK	糸切りクランク	1
19		402-63585	BLOCK	糸切りストッパー	1
20		402-63586	SCREW 3/16-28 L=14.5	止ねじ	1
21		402-63587	REPLACE SPRING	糸切り戻しばね	1
22		402-63588	DRIVE SHAFT	糸切り駆動軸	1
23		402-63589	BUSHING	糸切り駆動軸メタル左	1
24		402-63496	SCREW 1/4-40 L=8	止ねじ	2
25		402-63591	DRIVE SHAFT	糸切り駆動ピン	1
26		402-63592	CONNECTING ROD	連結リンク	1
27		402-63593	SCREW	止ねじ	2
28		402-63594	LIVE KNIFE ADJUST LINK	調節リンクＢ	1
29		402-63595	SCREW 11/64-40 L=9.5	止ねじ	1
30		402-63596	LIVE KNIFE ADJUST LINK	調節リンクＡ	1
31		402-63597	BUSHING	糸切り駆動軸メタル右	1
32		402-63598	TANGENT PIN	糸切り板	1
33		402-63465	TANGENT PLATE	ナット	1
34		402-63599	ROLLER	糸切りコロ	1
35		402-63600	AXIAL SCREW	糸切りコロ軸	1
36		402-63601	TANGENT CRANK	糸切りモーターリンク	1
37		402-63446	SCREW	止ねじ	2
38		402-63602	MOTOR MOUNTING PLATE NOE	モーター土台左	1
39		402-63603	MOTOR MOUNTING PLATE TWO	モーター土台右	1
40		402-63604	SNAPRING	Ｅリング	1
41		402-63605	SCREW	止ねじ	4
42		402-64700	SCREW	止めねじ	1

9. AUTOMATIC REVERSE FEED & NB COMPONENTS

自動逆送り・ＮＢ 関係






REF.NO	NOTE	PART NO	D E S C R I P T I O N	品　名	Qty
1		402-63606	REVEVSE SEWING SWITCH ASM.	ＴＢスイッチ組	1
2		402-63607	REVEVSE SEWING SWITCH	ＴＢスイッチ	(1)
3		402-63290	SCREW	止ねじ	(2)
4		402-63608	ELECTRIC CLAMP ASM.	糸押え組	1
5		402-63609	ELECTRIC CLAMP	糸押え	(1)
6		402-63610	SCREW	糸押え止ねじ	(1)

10. OIL LUBRICATION COMPONENTS


給油関係



REF.NO	NOTE	PART NO	D E S C R I P T I O N	品　名	Qty
1		402-63611	LUBRICATING OIL PUMP ASM.	ポンプ体組	1
2		402-63612	OIL PUMP INSTALLING BASE	ポンプ体組土台板	(1)
3		402-63613	SCREW 15/64-28 L=9	止ねじ	(3)
4		402-63614	OIL PUMP	オイルポンプ	(1)
5		402-63615	OIL PUMP BUSHING	オイルポンプメタル	(1)
6		402-63616	OIL PUMP IMPELLER	オイルポンプ羽	(1)
7		402-63617	OIL PUMP IMPELLER COVER	オイルポンプ羽カバー	(1)
8		402-63618	LUBRICAING OIL PUMP COVER	給油カバー	(1)
9		402-63619	SCREW	止ねじ	(3)
10		402-63620	HOOK DRIVING SHAFT OIL TUBE	給油パイプ	(1)
11		402-63621	PLUNGER	プランジャー	(1)
12		402-63622	PLUNGER SPRING	プランジャーばね	(1)
13		402-63623	SCREW	止ねじ	(1)
14		402-63624	SCREW	止ねじ	1
15		402-63625	SPONGE	スポンジ	1
16		402-63626	OIL PUMP SUPPORT	オイルポンプスタッド	1
17		402-63476	SCREW 11/64-40 L=9.5	止ねじ	1
18		402-63627	RUBBER JOINT	ジョイントゴム	1
19		402-63628	MAIN SHAFT OIL TUBE	上軸給油パイプ	1
20		402-63629	OIL TUBE	給油パイプ	1
21		402-63630	OIL ADJUSTING SCREW	釜油調節ねじ	1
22		402-63631	RUBBER RING	Oリング	1
23		402-64695	RETURN PIPE ASM.	還流パイプ(組)	1
24		402-63633	OIL RETURN TUBE HOLDER	還流パイプ固定板	(1)
25		402-63632	OIL RETURN GUARD	還流パイプ	(1)
26	*	402-90626	OIL FELT	還流フェルト	(1)
27		402-63635	OIL FELT PRESSER	還流フェルト押え	1
28		402-63636	OIL WICK SUPPORT ASM.	油防板組	1
29		402-63637	OIL WICK SUPPORT	油防板	(1)
30		402-63638	OIL WICK	油芯	(1)
31		402-63639	SCREW 1/8-44 L=4	止ねじ	(1)
32		402-63643	OIL JOINT	給油ジョイント	5
33		402-63644	OIL TUBE HOLDER	給油パイプ押え	4
34		402-63645	OIL TUBE	給油パイプ	2
35		402-63646	SCREW	止ねじ	2
36		402-63647	OIL_TUBE_HOLDER	給油パイプ押え	1
37		402-63648	OIL TUBE HOLDER	給油パイプ押え	1
38		402-63308	SCREW 1/8-28 L=6	止ねじ	1

11. OIL SHIELD COMPONENTS


オイルシールド関係



REF.NO	NOTE	PART NO	D E S C R I P T I O N	品　名	Qty
1		402-63649	OIL PLATE	オイルポット	1
2	*	402-90625	OIL PLATE GASKET	オイルポットパッキン	1
3		402-63651	OIL PLATE BATTLE	オイルポット板	1
4		402-63444	SCREW	止ねじ	6
5	*	402-90620	OIL EXPRACTION HOLE SCREW M8	排油ねじ	1
6		402-63653	RUBBER RING	Oリング	1
7		402-63654	SCREW	止ねじ	3
8		402-63655	RUBBER RING	Oリング	1
9		402-63656	SCREW	止ねじ	1
10		402-63657	PRESSURE PLATE	コード押え板	1
11		402-63658	SCREW	止ねじ	2
12		402-63659	MAGNET	磁石	1
13		402-63660	SCREW	止ねじ	1
14		402-63661	OIL PLATE SUBASSEMBLY	油量指示棒	1

12. THREAD STAND COMPONENTS


糸立装置関係



REF.NO	NOTE	PART NO	D E S C R I P T I O N	品　名	Qty
1		402-63663	THREAD STAND AMS.	糸立組	1
2		402-63664	COLUMN CAP	糸立棒キャップ	(1)
3		402-63665	COLUMN PIPE(UPPER)	糸立棒上	(1)
4		402-63666	SCREW	止ねじ	(2)
5		402-63667	THREAD GUIDE ARM JOINT	糸案内継手	(2)
6		402-63668	NUT	ナット	(2)
7		402-63669	THREAD GUIDE PIPE	糸道	(2)
8		402-63670	THREAD GUIDE BUSHING	糸道ブッシュ	(2)
9		402-63671	THREAD HANGER(2 SPOOLS TUPE)	糸立腕上	(1)
10		402-63672	COLUMN PIPE CONNECTOR	糸立棒継手	(1)
11		402-63673	COLUMN PIPE(LOWER)	糸立棒下	(1)
12		402-63674	WASHER	座金	(2)
13		402-63675	WASHER	座金	(1)
14		402-63676	SCREW	止ねじ	(2)
15		402-63677	NUT	ナット	(1)
16		402-63678	SPOOL PIN	糸巻受棒	(2)
17		402-63679	SPOOL CUSHION	糸巻振れ止め	(2)
18		402-63680	SOFT CUSHION OF THREAD PLARE	糸巻受皿クッション	(2)
19		402-63681	THREAD PLATE	糸巻受皿	(2)
20		402-63682	NUT	ナット	(4)
21		402-63683	THREAD HANGE(LOWER)	糸立腕下	(1)
22		402-63684	THREAD GUIDE RING	糸ガイド輪	(2)

13. ACCESSORIE PART COMPONENTS


付属品関係



REF.NO	NOTE	PART NO	D E S C R I P T I O N	品　名	Qty
1		402-63685	SCREW DRIVER (SMALL)	ドライバー小	1
2		402-63686	SCREW DRIVER (MIDDLE)	ドライバー中	1
3		402-63687	SCREW DRIVER (LARGE)	ドライバー大	1
4		402-63688	HINGE COMPL	頭部ひんじ	2
5		402-63689	NAIL	釘	8
6		402-63690	RUBBER CUSHION	頭部ひんじゴム	2
7		402-63395	NEEDLE	針	4
8		402-63473	BOBBIN	ボビン	3
9		402-15706	PEDAL_SENSOR_BASE_ASSY	ペダルセンサ組	1
10		402-63692	FRAMEVINYL COVER	頭部カバー	1
11		402-63693	FUNNEL	漏斗	1
12		402-63694	NOSE SUPPORT	頭部支えゴムＡ	2
13		402-63695	OILER ASM.	油挿し	1
14		402-63696	DIE CUSHION	頭部支えゴムＢ	2
15		402-63697	WRENCH	六角レンチ４mm	1
16		402-63698	WRENCH	六角レンチ３mm	1
17		402-63699	WRENCH	六角レンチ２.５mm	1
18		402-63700	SCREW	止ねじ	6
19		402-64644	SCREW	止ねじ	1
20		402-64645	BENT SHAFT	膝上げ棒	1
21		402-64646	SOFT MAT	膝上げパット	1
22		402-64647	MAT	膝上げパットナット	1
23		402-64648	PLATE	膝上げパット板Ａ	1
24		402-64649	JOINT SCREW	止ねじ	1
25		402-64650	JOINT	膝上げパット板Ｂ	1
26		402-64651	JOINT	調整ジョイント	1
27		402-64652	PEDAL LEVER	ペダル連結棒	1
28		402-63283	OIL BOTTLE WITH OIL	ＪＵＫＩマシーンオイル	1
29		402-64653	RUBBER MAT	オイル箱蓋	1
30		402-64654	ELECTRONIC KNEES BY	電気式膝上げ装置	1
31		402-64655	DISK TRAY	アンダーカバー	1
32		402-64675	ACCESSORY_BAG	付属品袋	1

14. FOR HEAVY-WEIGHT MATERIALS

厚物専用



REF.NO	NOTE	PART NO	D E S C R I P T I O N	品　名	Qty
1		402-64656	NEEDLE GUIDE H-TYPE	針棒糸案内H	1
2		402-64657	NEEDLE H-TYPE	針棒H	1
3		402-64658	NEEDLE LOWER METAL H-TYPE	針棒下メタルH	1
4		114-00801	NEEDLE PLATE H-TYPE	針板H	1
5		402-64660	PRESSER FOOT ASM. H-TYPE	押え組H	1
6		402-64662	THREAD TAKE-UP ASM. H-TYPE	天秤組H	1
7		402-64663	CONNECTING ROD ASM. H-TYPE	水平上下偏心カム組H	1
8		402-64664	COUNTER WEIGHT H-TYPE	釣合錘H	1
9		402-64665	NEEDLE H-TYPE	針H	1
10		402-64666	OIL SHIELD H-TYPE	油防板H	1
11		402-64667	THREAD TENSION ASM. H-TYPE	糸調子組H	1
12		402-64687	TAKE-UP SPRING H-TYPE	糸取りばねH	(1)
13		402-64688	TENSION SPRING H-TYPE	第二糸調子ばねH	(1)
14	#03	402-64690	HOOK_ASM.(H)	釜(組)__H仕様	1
15		402-64669	POSTIONING FINGER H-TYPE	内釜留めH	1
16	#02	402-64670	HOOK_ASM.(H)	釜(組)__H仕様	1
17		402-62398	NEEDLE BAR THREAD GUIDE H-TYPE	針棒糸掛けH	1
18		114-03003	FEED DOG H-TYPE	送り歯H	1
19	#01	229-62054	THREAD TENSION ASM. H-TYPE	糸調子組H	1
		NOTE(注記)	#01....SPARE PARTS #02....FOR CHINA #03....FOR GENERAL EXPORT	補用パーツ 中国向け 一般輸出用	

15. LIST FOR INFORMATION OF CHANGE

変更情報リスト

As to the place changed, refer to the corresponding Rev. No.
When previous parts (Obsoleted part) and new parts (Added parts) are not interchangeable with each other:
In this case, even obsoleted parts (D.) can be ordered with the obsoleted part number, so select the parts with changed dates and place your orders.

変更箇所は，該当Rev. No. 版をご参照ください。
部品の互換性がない変更の場合は，削除された品番でも，ご注文できます。

No. 1767−10・・・Rev. No.

＊A：Added parts追加部品／D：Obsoleted parts削除部品／E：Erratum訂正

＊	Rev. No.	Page 頁	Ref. No.	Parts No. 品番	＊	Rev. No.	Page 頁	Ref. No.	Parts No. 品番
D	09	2	13	402−63296					
D	09	2	19	402−63304					
D	09	8	45	402−63469	A	10	8	45	402−90629
D	09	12	21	402−63516	A	10	12	21	402−93984
					A	10	12	53	402−90621
D	09	14	9	402−63553	A	10	14	9	402−90622
D	09	20	26	402−63634	A	10	20	26	402−90626
D	09	22	2	402−63650	A	10	22	2	402−90625
D	09	22	5	402−63652	A	10	22	5	402−90620

NUMERICAL INDEX OF PARTS
索引

PART NO 品番	PAGE 頁	REF NO
114-00801	28	4
114-03003	28	18
229-02506	2	38
229-62054	28	19
402-15706	26	9
402-59438	2	43
402-59439	2	44
402-62397	2	13
402-62398	28	17
402-62399	2	64
402-63283	26	28
402-63284	2	1
402-63285	2	2
402-63286	2	3
402-63287	2	4
402-63288	2	5
402-63289	2	6
402-63290	2	7
402-63290	6	35
402-63290	14	25
402-63290	18	3
402-63291	2	8
402-63292	2	9
402-63293	2	10
402-63294	2	11
402-63295	2	12
402-63297	2	14
402-63298	2	15
402-63299	2	16
402-63299	14	24
402-63301	4	16
402-63302	2	17
402-63303	2	18
402-63305	2	20
402-63306	2	21
402-63307	2	22
402-63308	2	23
402-63308	20	38
402-63309	2	24
402-63310	2	25
402-63311	2	26
402-63312	2	27
402-63313	2	28
402-63314	2	29
402-63315	2	30
402-63316	2	31
402-63317	2	32
402-63318	2	33
402-63319	2	34
402-63320	2	35
402-63321	2	36
402-63322	2	37
402-63323	2	39
402-63324	2	40
402-63325	2	63
402-63326	2	19
402-63330	2	45
402-63330	4	31
402-63330	6	30
402-63333	2	46
402-63334	2	47
402-63335	2	48
402-63336	2	49
402-63337	2	50
402-63338	2	51
402-63339	2	52
402-63340	2	53
402-63341	2	54
402-63342	2	55
402-63343	2	56
402-63344	2	57
402-63346	4	1
402-63347	4	2
402-63348	4	3
402-63349	4	4
402-63350	4	5
402-63351	4	6
402-63352	4	7
402-63353	4	8
402-63354	4	9
402-63355	4	10
402-63356	4	11
402-63357	4	12
402-63358	4	13
402-63359	4	14
402-63361	4	15
402-63362	4	17
402-63363	4	18
402-63365	4	20
402-63366	4	41
402-63366	8	40
402-63366	14	3
402-63366	14	5
402-63371	4	22
402-63372	4	23
402-63373	4	24
402-63374	4	25
402-63375	4	26
402-63376	4	27
402-63377	4	28
402-63378	4	29
402-63379	4	35
402-63380	4	32
402-63381	4	33
402-63382	4	34
402-63383	4	30
402-63384	4	36
402-63385	4	37
402-63386	4	38
402-63387	4	39
402-63388	6	1
402-63389	6	2
402-63390	6	3
402-63391	6	4
402-63392	6	5
402-63393	6	6
402-63394	6	7
402-63395	6	8
402-63395	26	7
402-63396	6	9
402-63397	6	10
402-63398	6	11
402-63399	6	13
402-63400	6	39
402-63401	6	14
402-63402	6	15
402-63403	6	16
402-63404	6	27
402-63405	6	18
402-63406	6	19
402-63407	6	20
402-63408	6	21
402-63409	6	22
402-63410	6	23
402-63411	6	24
402-63412	6	25
402-63413	6	26
402-63414	6	40
402-63415	6	28
402-63416	6	29
402-63417	6	31
402-63418	6	32
402-63419	6	33
402-63420	6	34
402-63421	6	36
402-63422	6	37
402-63423	6	38
402-63424	8	1
402-63425	8	2
402-63426	8	3
402-63427	8	4
402-63428	8	5
402-63429	8	6
402-63430	8	7
402-63431	8	8
402-63432	8	9
402-63433	8	10
402-63434	8	11
402-63434	8	13
402-63435	8	12
402-63436	8	14
402-63437	8	15
402-63438	8	18
402-63439	8	17
402-63440	8	24
402-63441	8	19
402-63442	8	29
402-63443	8	25
402-63444	8	44
402-63444	22	4
402-63445	8	23
402-63446	8	30
402-63446	14	14
402-63446	16	3
402-63446	16	37
402-63447	8	21
402-63448	8	20
402-63449	8	26
402-63450	8	27
402-63451	8	22
402-63452	8	28
402-63454	8	31
402-63455	8	32
402-63456	8	33
402-63457	8	34
402-63458	8	35
402-63459	8	36
402-63460	8	37
402-63461	8	38
402-63462	8	39
402-63464	8	41
402-63465	8	42
402-63465	16	33
402-63467	8	43
402-63468	8	16
402-63470	8	46
402-63470	10	28
402-63471	10	1
402-63472	10	2
402-63473	10	3
402-63473	26	8
402-63474	10	4
402-63474	10	11
402-63475	10	5
402-63476	10	6
402-63476	20	17
402-63477	10	7
402-63478	10	8
402-63479	10	9
402-63480	10	10
402-63482	10	12
402-63484	10	15
402-63485	10	16
402-63486	10	17
402-63487	10	18
402-63488	10	19
402-63489	10	20
402-63490	10	21
402-63491	10	22
402-63492	10	23
402-63493	10	24
402-63494	10	25
402-63495	10	14
402-63495	10	26
402-63496	10	27
402-63496	16	24
402-63497	12	2
402-63498	12	6
402-63499	12	3
402-63500	12	4
402-63501	12	5
402-63502	12	15
402-63503	12	7
402-63504	12	8
402-63504	12	52
402-63505	12	9
402-63506	12	10
402-63507	12	33
402-63508	12	12
402-63509	12	40
402-63510	12	38
402-63511	12	39
402-63512	12	34
402-63513	12	16
402-63514	12	41
402-63515	12	17
402-63517	12	22
402-63518	12	23
402-63519	12	24
402-63521	12	26
402-63522	12	27
402-63523	12	28
402-63524	12	29
402-63526	12	31
402-63527	12	32
402-63528	12	18
402-63529	12	19
402-63530	12	35
402-63531	12	36
402-63532	12	37
402-63533	12	20
402-63534	12	14
402-63535	12	13
402-63536	12	11
402-63537	12	42
402-63538	12	43
402-63539	12	44
402-63540	12	45
402-63541	12	46
402-63542	12	47
402-63543	12	48
402-63544	12	49
402-63545	12	50
402-63546	14	1
402-63547	14	2
402-63548	14	4
402-63550	14	6
402-63551	14	7
402-63552	14	8
402-63554	14	10
402-63555	14	11
402-63556	14	12
402-63557	14	13
402-63558	14	15
402-63559	14	16
402-63560	14	17
402-63561	14	18
402-63562	14	19
402-63563	14	20
402-63564	14	21
402-63565	14	22
402-63566	14	23
402-63567	16	1
402-63568	16	2
402-63570	16	4
402-63571	16	5
402-63572	16	6
402-63573	16	7

PART NO 品番	PAGE 頁	REF NO
402-63574	2	62
402-63575	16	9
402-63576	16	10
402-63577	16	11
402-63578	16	12
402-63579	16	13
402-63580	16	14
402-63581	16	15
402-63582	16	16
402-63583	16	17
402-63584	16	18
402-63585	16	19
402-63586	16	20
402-63587	16	21
402-63588	16	22
402-63589	16	23
402-63591	16	25
402-63592	16	26
402-63593	16	27
402-63594	16	28
402-63595	16	29
402-63596	16	30
402-63597	16	31
402-63598	16	32
402-63599	16	34
402-63600	16	35
402-63601	16	36
402-63602	16	38
402-63603	16	39
402-63604	16	40
402-63605	16	41
402-63606	18	1
402-63607	18	2
402-63608	18	4
402-63609	18	5
402-63610	18	6
402-63611	20	1
402-63612	20	2
402-63613	20	3
402-63614	20	4
402-63615	20	5
402-63616	20	6
402-63617	20	7
402-63618	20	8
402-63619	20	9
402-63620	20	10
402-63621	20	11
402-63622	20	12
402-63623	20	13
402-63624	20	14
402-63625	20	15
402-63626	20	16
402-63627	20	18
402-63628	20	19
402-63629	20	20
402-63630	20	21
402-63631	20	22
402-63632	20	25
402-63633	20	24
402-63635	20	27
402-63636	20	28
402-63637	20	29
402-63638	20	30
402-63639	20	31
402-63643	20	32
402-63644	20	33
402-63645	20	34
402-63646	20	35
402-63647	20	36
402-63648	20	37
402-63649	22	1
402-63651	22	3
402-63653	22	6
402-63654	22	7
402-63655	22	8
402-63656	22	9
402-63657	22	10
402-63658	22	11
402-63659	22	12
402-63660	22	13
402-63661	22	14
402-63663	24	1
402-63664	24	2
402-63665	24	3
402-63666	24	4
402-63667	24	5
402-63668	24	6
402-63669	24	7
402-63670	24	8
402-63671	24	9
402-63672	24	10
402-63673	24	11
402-63674	24	12
402-63675	24	13
402-63676	24	14
402-63677	24	15
402-63678	24	16
402-63679	24	17
402-63680	24	18
402-63681	24	19
402-63682	24	20
402-63683	24	21
402-63684	24	22
402-63685	26	1
402-63686	26	2
402-63687	26	3
402-63688	26	4
402-63689	26	5
402-63690	26	6
402-63692	26	10
402-63693	26	11
402-63694	26	12
402-63695	26	13
402-63696	26	14
402-63697	26	15
402-63698	26	16
402-63699	26	17
402-63700	26	18
402-64644	26	19
402-64645	26	20
402-64646	26	21
402-64647	26	22
402-64648	26	23
402-64649	26	24
402-64650	26	25
402-64651	26	26
402-64652	26	27
402-64653	26	29
402-64654	26	30
402-64655	26	31
402-64656	28	1
402-64657	28	2
402-64658	28	3
402-64660	28	5
402-64662	28	6
402-64663	28	7
402-64664	28	8
402-64665	28	9
402-64666	28	10
402-64667	28	11
402-64669	28	15
402-64670	28	16
402-64671	2	58
402-64672	2	59
402-64673	2	60
402-64674	2	61
402-64675	26	32
402-64676	4	19
402-64677	4	21
402-64678	12	51
402-64679	2	41
402-64680	6	17
402-64681	6	12
402-64682	12	1
402-64687	28	12
402-64688	28	13
402-64689	10	29
402-64690	28	14
402-64695	20	23
402-64696	4	42
402-64697	10	13
402-64699	16	8
402-64700	16	42
402-90620	22	5
402-90621	12	53
402-90622	14	9
402-90625	22	2
402-90626	20	26
402-90628	12	25
402-90629	8	45
402-93984	12	21
402-99184	4	40
403-00798	2	42
403-06440	12	30